



Please note that Cypress is an Infineon Technologies Company.

The document following this cover page is marked as “Cypress” document as this is the company that originally developed the product. Please note that Infineon will continue to offer the product to new and existing customers as part of the Infineon product portfolio.

Continuity of document content

The fact that Infineon offers the following product as part of the Infineon product portfolio does not lead to any changes to this document. Future revisions will occur when appropriate, and any changes will be set out on the document history page.

Continuity of ordering part numbers

Infineon continues to support existing part numbers. Please continue to use the ordering part numbers listed in the datasheet for ordering.



EZ-PD Protocol Analyzer Utility Release Notes

Version 3.1.0, September 11, 2020

Thank you for your interest in EZ-PD™ Protocol Analyzer Utility 3.1.0. This document lists the installation requirements and installed contents in the latest version of the utility.

System Requirements and Recommendations

Hardware Requirements	Minimum	Recommended
Processor Speed	1 GHz	2 GHz
RAM	2 GB	4 GB
Free Hard Drive Spec	5 GB	10 GB
Screen Resolution	1024x768	1280x1024
USB	Full Speed	USB 2.0 (High Speed)
Operating System Requirements	Minimum	Recommended
Windows	Windows 7	Windows 10
macOS	Mojave (10.14)	Mojave (10.14) or higher
Linux	Ubuntu 18.04/ Fedora 31	Ubuntu 18.04 or higher/ Fedora 31 or higher
Software Pre-requisites	Minimum	Recommended
Adobe Reader (for PDF Documentation)	6	9+
Java Runtime Engine	1.8	1.8
.Net Framework	4.0	4.0

Installation in Windows

Download and install the latest version of the EZ-PD Protocol Analyzer Utility. By default, the utility is installed under *<Install Directory>\EZ-PD Protocol Analyzer Utility* directory.

Note: The default *<Install Directory>* is *C:\Users\{%USERPROFILE%}\Cypress*.

The utility can be invoked from Windows Start Menu > Cypress > EZ-PD Protocol Analyzer Utility.

Installation in macOS

Download the latest version of the EZ-PD Protocol Analyzer Utility. Open the extracted zip package to run EZ-PD Protocol Analyzer Utility 3.1.0.

Installation in Linux Distributions

Download the latest version of the EZ-PD Protocol Analyzer Utility. Extract the zip package and open a terminal inside the extracted directory.

Execute the following one-time commands:

```
export SWT_GTK3=0  
chmod a+x CY4500_EZ_PD_Protocol_Analyzer_UTILITY
```



The EZ-PD Protocol Analyzer Utility 3.1.0 should be invoked in superuser mode.

Command:

```
sudo ./CY4500_EZ_PD_Protocol_Analyzer_Utility
```

Supported Kit

This version of EZ-PD Protocol Analyzer Utility works with CY4500 EZ-PD Protocol Analyzer from Cypress for capturing PD traffic.

Features of EZ-PD Protocol Analyzer Utility

1. Supports decoding for PD 2.0, PD 3.0, Extended messages and USB4 messages.
2. Supports Graphical interpretation of PD messages
3. Supports live display of CC and VBUS voltage and current
4. Allows Enable/Disable of Graphical data
5. Provides import option to import *.csv and *.xlsx files from previous version of the Analyzer Utility
6. Provides option to export traces to *.csv format
7. Provides Theme selection (Default-Black, Blue, and Gray)
8. Find Message: Go to specified PD-message line based on column value

Changes from 3.0 Build 15 to 3.1.0 Build 31

1. Fixed a data capture issue during reconnection of the target device to the CY4500 Analyzer hardware
2. Enhanced decoding of the Discover identity command to display DFP and UFP VDO
3. Updated USB4 message decoding
4. Updated decoding support for Display Port Alt mode
5. Fixed issues in Reset Perspective option from the Window menu
6. Enhanced the filtering functionality to display the values present in the captured data
7. Fixed RDO decoding issue
8. Fixed issues in Extended message decoding
9. Updated the Firmware Update tool

Limitations/Known Issues

1. Trigger feature is not supported in this release.
2. The maximum voltage measured on the CC lines is 3.3 V.

Documentation

The following documents are available in *<Install Directory>* (the *<Install Directory>* is user extracted location).

1. Documents/EZ-PD_Analyzer_UserGuide.pdf
2. ReleaseNotes.pdf

Technical Support

For assistance, go to www.cypress.com/support.



Additional Information

For more information about Cypress' USB Type-C Controller Solutions, visit <https://www.cypress.com/products/usb-type-c-and-power-delivery>.



Cypress Semiconductor
An Infineon Technologies Company
198 Champion Court
San Jose, CA 95134-1709
www.cypress.com
www.infineon.com

© Cypress Semiconductor Corporation, 2020. This document is the property of Cypress Semiconductor Corporation and its subsidiaries ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. No computing device can be absolutely secure. Therefore, despite security measures implemented in Cypress hardware or software products, Cypress shall have no liability arising out of any security breach, such as unauthorized access to or use of a Cypress product. CYPRESS DOES NOT REPRESENT, WARRANT, OR GUARANTEE THAT CYPRESS PRODUCTS, OR SYSTEMS CREATED USING CYPRESS PRODUCTS, WILL BE FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION (collectively, "Security Breach"). Cypress disclaims any liability relating to any Security Breach, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from any Security Breach. In addition, the products described in these materials may contain design defects or errors known as errata which may cause the product to deviate from published specifications. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. "High-Risk Device" means any device or system whose failure could cause personal injury, death, or property damage. Examples of High-Risk Devices are weapons, nuclear installations, surgical implants, and other medical devices. "Critical Component" means any component of a High-Risk Device whose failure to perform can be reasonably expected to cause, directly or indirectly, the failure of the High-Risk Device, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from any use of a Cypress product as a Critical Component in a High-Risk Device. You shall indemnify and hold Cypress, its directors, officers, employees, agents, affiliates, distributors, and assigns harmless from and against all claims, costs, damages, and expenses, arising out of any claim, including claims for product liability, personal injury or death, or property damage arising from any use of a Cypress product as a Critical Component in a High-Risk Device. Cypress products are not intended or authorized for use as a Critical Component in any High-Risk Device except to the limited extent that (i) Cypress's published data sheet for the product explicitly states Cypress has qualified the product for use in a specific High-Risk Device, or (ii) Cypress has given you advance written authorization to use the product as a Critical Component in the specific High-Risk Device and you have signed a separate indemnification agreement.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.