

Downloading Firmware to CYW20732 Modules Using BlueTool™

Associated Part Family: CYW20732

This document describes the step-by-step process of downloading firmware to CYW20732 modules using BlueTool™ software. It is intended for developers who are using the CYW20732.

1 About this Document

1.1 Cypress Part Numbering Scheme

Cypress is converting the acquired IoT part numbers from Broadcom to the Cypress part numbering scheme. Due to this conversion, there is no change in form, fit, or function as a result of offering the device with Cypress part number marking. The table provides Cypress ordering part number that matches an existing IoT part number.

Table 1. Mapping Table for Part Number between Broadcom and Cypress

Broadcom Part Number	Cypress Part Number
BCM20732	CYW20732

1.2 Acronyms and Abbreviations

In most cases, acronyms and abbreviations are defined on first use.

For a comprehensive list of acronyms and other terms used in Cypress documents, go to:
<http://www.cypress.com/glossary>


2 IoT Resources

Cypress provides a wealth of data at <http://www.cypress.com/internet-things-iot> to help you to select the right IoT device for your design, and quickly and effectively integrate the device into your design. Cypress provides customer access to a wide range of information, including technical documentation, schematic diagrams, product bill of materials, PCB layout information, and software updates. Customers can acquire technical documentation and software from the Cypress Support Community website (<http://community.cypress.com/>).

3 Using BlueTool™ to Download Firmware

3.1 Establish Communications

1. Connect the CYW20732 reference board(s) to the computer with a UART cable and power up the device.
2. Open BlueTool™, and then, from the **View** menu, select **Log Window** to display an empty log window.
3. From the **Transport** menu, Select **HCI Control**.
4. In the Select HCI Control Window Transport window:
 - a. Select **UART, com1, and 115200**.
 - b. Verify that **CTS flow control** is *not* selected.
 - c. Click **OK** to save the changes and return to the HCI Control command window.



5. In the HCI Control Command window:
 - a. Enable **HCI protocol active**.
 - b. From the top-right list box, select **7.3: Host Controller & Baseband Commands (3 key)**.
 - c. In the main pane, double-click **Reset**.

Note: After a successful reset, the last line in the log window will read:
Status = 0x0 (0, "Success").



3.2 Download the Firmware

1. From the BlueTool **Transport** menu, select **Download Firmware/Config**.
2. In the Select Download Firmware/Config Transport window (different title bar, but the window is the same as that shown in [Step 4 on page 1](#)):
 - a. Select **UART, com1**, and **115200**.
 - b. Verify that **CTS flow control** is *not* selected.
 - c. Click **OK** to display the Download window
3. In the **Download** window, make the settings shown in the table below.

	EEPROM Settings (see Figure)	Serial Flash Settings (see Figure)
From the Device configuration drop-down list box (upper-left corner), select:		
	64-Byte	4-KByte
In the group near the upper-right corner:		
From the drop-down list boxes:	Select: <input checked="" type="checkbox"/> Cortex M3 HCI <input checked="" type="checkbox"/> Write and verify <input checked="" type="checkbox"/> Chip erase	Select: <input checked="" type="checkbox"/> ARM HCI <input checked="" type="checkbox"/> Write and verify <input checked="" type="checkbox"/> Chip erase
In the Max write size field, enter:	16	48
In the Download minidriver group:		
	<input checked="" type="checkbox"/> Enable Download minidriver . <input checked="" type="checkbox"/> Click Locate , then navigate to and select the uart.hex file.	
In the Download configuration record group:		
	<input checked="" type="checkbox"/> Enable Download configuration record <input checked="" type="checkbox"/> Click Locate , then navigate to and select the desired cgs/cgr file.	

	EEPROM Settings (see Figure)	Serial Flash Settings (see Figure)
From the drop-down list box, select:	EEPROM as the memory.	
In the DS location field, enter:	0x000002C0	0x00003000
Enable Include static section .		
From the Crystal frequency (MHz) drop-down list box, select:	24 MHz	24 MHz preset
In the BD_ADDR field, enter:	The desired Bluetooth device address .	
Enable Omit RF_PLL (65 nm radio)		
In the VS Location field, enter:	0x000000C0	0x00001000
In the VS length field, enter:	0x0200	0x1000
In the upper-right corner of the window, click Execute to begin the firmware download.		

When the download is complete, **Status** (upper-right area of the download window) will change from **Idle** to **Download completed**.

After power to the device is cycled, the CYW20732 is ready for normal operation.

Figure 1. 20732 EEPROM





Figure 2. 20732 Serial Flash



Document History Page

Document Title: AN215042 - Downloading Firmware to CYW20732 Modules Using BlueTool™				
Document Number: 002-15042				
Rev.	ECN No.	Orig. of Change	Submission Date	Description of Change
**	-	-	02/09/2012	20732-AN100-R Initial release
*A	5473213	UTSV	10/13/2016	Updated to Cypress template. Added Cypress Part Numbering Scheme.

Worldwide Sales and Design Support

Worldwide Sales and Design Support

Cypress maintains a worldwide network of offices, solution centers, manufacturers' representatives, and distributors. To find the office closest to you, visit us at [Cypress Locations](#).

Products

ARM® Cortex® Microcontrollers	cypress.com/arm
Automotive	cypress.com/automotive
Clocks & Buffers	cypress.com/clocks
Interface	cypress.com/interface
Internet of Things	cypress.com/iot
Lighting & Power Control	cypress.com/powerpsoc
Memory	cypress.com/memory
PSoC	cypress.com/psoc
Touch Sensing	cypress.com/touch
USB Controllers	cypress.com/usb
Wireless/RF	cypress.com/wireless

PSoC® Solutions

[PSoC 1](#) | [PSoC 3](#) | [PSoC 4](#) | [PSoC 5LP](#)

Cypress Developer Community

[Forums](#) | [WICED IOT Forums](#) | [Projects](#) | [Video](#) | [Blogs](#) | [Training](#) | [Components](#)

Technical Support

cypress.com/support



Cypress Semiconductor
198 Champion Court
San Jose, CA 95134-1709

Phone : 408-943-2600
Fax : 408-943-4730
Website : www.cypress.com

© Cypress Semiconductor Corporation, 2012-2016. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.